

# "ALUPLAST" SHELVING ASSEMBLY INSTRUCTIONS

**1** INSERT UPRIGHTS INTO THE SHELF FROM THE TOP, KEEPING THE SHELF INCLINED AS PER FIGURE. [FIGURE] UPRIGHT GROOVE. INNER RING OF THE BUSHING.

**2** MOUNT THE BUSHING ONTO THE UPRIGHT AT THE REQUIRED HEIGHT.

**3** FIX THE SHELVES ONTO THE BUSHINGS, AS INDICATED IN THE FIGURE.

**!** ENSURE THE BUSHING IS INSERTED PROPERLY INTO THE GROOVE, OTHERWISE THE SHELF COULD SLIDE.

**!** MAKE SURE THAT THE BUSHING WON'T SLIDE ON THE UPRIGHT DURING THE FITTING OF THE SHELF.

**4** INSERT BUSHINGS FOR THE NEXT SHELF AND FIX INTO PLACE AS PER FIGURE 3.

**5** INSERT THE GRATES ONTO THE SHELVES.

# RACK ASSEMBLY INSTRUCTIONS

**6** MOUNTING OF JOINT FOR UNION OF SHELVES: LONG SIDE OF JOINT IS "CLICKED" ONTO THE ALREADY-ASSEMBLED SHELF (SEE ENLARGED FIGURE).

**!** FAILURE TO MOUNT JOINT CORRECTLY WILL COMPROMISE THE STABILITY OF THE RACK.

UPPER LONG SIDE  
LOWER TAB

**7** JOIN THE NEXT SHELF WITH THE SHELF THAT HAS THE UPRIGHTS ALREADY INSERTED. ENSURE THE SHELVES ARE JOINED CORRECTLY ALONG THE LOWER TAB OF THE JOINT (SEE ENLARGED FIGURE).

**8** FIX THE SHELF ONTO THE JOINTS USING HAND PRESSURE.

# TRANSVERSAL RACK ASSEMBLY INSTRUCTIONS

**6** CUT EDGE OF GRATE TO ALLOW MOUNTING OF JOINTS.

INSERT GRATE ONTO SHELF.

**7** MOUNT JOINTS FOR UNION OF SHELVES

**!** SEE "RACK ASSEMBLY INSTRUCTIONS"

UPPER LONG SIDE  
LOWER TAB

**8** FIX THE SHELF ONTO THE JOINTS USING HAND PRESSURE.